

Repair instruction

Description: Flush tube C3 Part number: 20103 10/62

Look for Service Centers, Point of Sale addresses and other

information on: www.thetford-europe.com

Version:	V1
Date:	23/05/2006
Tools required:	-

Α

C3 toilet.



Tissue well

T-1

В

out.

Take the tissue holder out.

Take the tissue well





Inside view.



Push up the cableassy.





Pull the nozzle (inside the toilet) down.

23/05/2006

Description: Flush tube C3

1

Remove the vacuum breaker by pressing against the upstanding rib.

> Remove the tube from the vacuum breaker and place the new tube on the vacuum breaker.





Replace the vacuum breaker by pressing against the upstanding rib.

Replace the nozzle inside the water tank (you have to hear a click while replacing). The rib has to go inside of the toilet bowl.



Push down the





cable-assy.

Refit the tissue

holder.





G

Refit the tissue well.



